


Guide


- [Interface Overview](#)
- [Output Types](#)
- [Appendix](#)

Interface Overview




1. **Listening Port** - Specify the port for Ayva WebSocket Hub to monitor incoming connections. Any [TCode](#) received on this port will be routed to the connected outputs. Click the *Start* button to begin monitoring for incoming connections. Data forwarding will commence immediately upon establishing a connection.
2. **Add Output** - Use this dropdown menu to select and add output streams.
3. **Outputs** - This table lists all configured outputs—which are saved across sessions—along with their connection status. You can enable or disable streaming to any listed output by using the checkbox in the *Enabled* column.
4. **Incoming Connection State** - This indicates the status of the incoming connection, which can be *Disconnected*, *Listening* or *Connected*.
5. **Patreon Link** - Ayva Software is supported by the community. This is a link to the [Patreon](#).

Output Types



There are two main types of outputs: **Network** and **Serial**.



Network



Network outputs enable connections to devices or software via [TCP](#) or [UDP](#) protocols. In TCP mode, Ayva WebSocket Hub attempts to establish a connection to a WebSocket at the `/ws` endpoint on the specified host and port. In UDP mode, packets are sent directly to the designated host and port. Note that because UDP is *connectionless*, a UDP output will always be displayed as *Connected*, even if no application or device is actively listening at the specified host and port.

TCP is typically used to connect to WiFi-enabled devices, while UDP is typically used to stream to a [Virt-a-mate](#) plugin such as [BusDriver](#) (though it can also be used for WiFi-enabled devices that support UDP).



Serial






Serial outputs facilitate device connections via the Serial protocol, typically through USB. However, they can also operate over [virtual serial ports](#) that emulate physical connections for other protocols, including Bluetooth Classic.

Appendix


To be incorporated into the Guide







Example: Streaming from Ayva Stroker Lite



Output Range

Disconnected

stroke

0.00

1.00

surge

0.00

1.00

sway

0.00

1.00

twist

0.00

1.00

roll

0.00

1.00

pitch

0.00

1.00

Mode: Stopped

Output Settings

Type: WebSocket

Host: localhost

Port: 8080

Note: There currently is no firmware available that supports a secure WebSocket. You must connect to another application running on localhost, such as Ayva WebSocket Hub (coming soon!)

60

Current BPM

Home Device

Free Play (Speed)

Stop (Speed)

Parameters

8080

Change BPM

On Transition

BPM Range

10 - 10

Acceleration (bpm/s)

0 - 0.1

Pattern Duration

3.0s - 6.0s

Transition Duration

2.0s - 5.0s

Default Twist

Twist Range

0.25 - 0.75

Twist Phase

0.00

Twist Eccentricity

0.00

Strokes

Select or manually trigger a stroke

stroke-sequence

back-thrust-down

back-thrust-down-swirl

diagonal-down-back

diagonal-down-forward

down-backward

down-forward

forward-back-grind

forward-back-tease

grind-circular

grind-forward-back

grind-forward-back-phased