

Notes

This page is a messy, temporary page to post links and/or notes that might be useful for beginners. Eventually this will be compiled into a more coherent guide.

Stuff needed:

- USB Serial Drivers: <https://www.silabs.com/developers/usb-to-uart-bridge-vcp-drivers?tab=downloads>

How to connect to PC / macOS

What software is available.

guide for each software.

Revision #2

Created 9 November 2023 23:16:45 by Sorites Paradox

Updated 3 December 2023 00:24:40 by Sorites Paradox